



NOTES:

1. CENTER VALVE BOX OVER OPERATING NUT TO INSURE FREE VALVE OPERATION.
2. USE 6" RISER PIPE ON 4" & 6" VALVES.
3. USE 8" RISER PIPE ON 8" VALVES AND LARGER.
4. REFER TO MINIMUM STANDARDS FOR ACCEPTABLE MANUFACTURERS.
5. DO NOT ALLOW VALVE BOX OR RISER TO REST ON ANY PORTION OF VALVE.

TYPICAL VALVE BOX

CHARLESTON WATER SYSTEM		
TYPICAL VALVE BOX		
APPROVED BY: CWS	DATE: MAR 2000	DRAWING NO. 10
SCALE: NTS	REVISED: FEB 2010	